

COLD BREW COFFEE



COLD BREW SYSTEM
HOW TO INSTRUCTIONS

Curtis[®]



How to make Cold Brew Coffee

Instructions (Makes 4 gallons)

- 1 Place Toddy Coffee Strainer inside the Curtis TC-6H or TC-7H.
- 2 Place Toddy One-time Paper Filter inside the strainer.
- 3 Pour 5 lbs. of ground coffee into the paper filter.
- 4 Gently pour 1 gallon of water over the coffee grounds, making sure to saturate as evenly as possible.
- 5 Tie the paper filter at the top securely with string.
- 6 Pour the remaining 3 gallons of water into the Cold Brew Coffee System.
- 7 Place lid on top of the unit and steep at room temperature 12-16 hours.
- 8 After 12-16 hours have passed, lift up the coffee strainer and paper filter inside. Allow coffee to completely drip out before removing.
- 9 Discard coffee grounds and paper filter. Rinse the coffee strainer and allow to air dry before using again.
- 10 Add water to coffee concentrate in the ratio according to your recipe (2:1 water to concentrate is a great place to start) and serve over ice. Store in refrigerator. Enjoy!

